

SL Lock Installation

1. Remove existing buckle and catch. Replace buckle and catch with SL Lock buckle. The SL Lock catch should be attached so that the spring is to the inside of the boot. Make sure that the spring and protecting metal lever are working freely. If you are installing a SL Lock on a Dobermann older than 2006, you will have to remove material (grind plastic) from the cuff under the spring so that the lever and spring can open and close.

*Note that both the SL Lock buckle and SL Lock catch need to be used because the original Dobermann buckle's bail is too narrow to fit around and in the SL Lock catch.

